

Indicator Light

LH 96

The Dualamp Indicator Light lampholder is used for direct current applications and where personnel safety must be obtained without putting a ground on the system. The lamp sockets are recessed into an insulated core and the circuit is automatically disconnected when the lens is removed to replace the lamps. The two lamps are connected to a resistor contained within the unit.



JHSLC P/N	Primary VAC	Secondary VAC	Resistor Rating	Lamp Accomodation	Lenses Available
LH 96/1	6	6	none		
LH 96/2	12	6	300 ohm 5 W		
LH 96/3	24	6	600 ohm 5 W	W-L-00111/46	LC 38
LH 96/4	48	6	1200 ohm 5 W	(#342:MS15612-5	thru 45
LH 96/5	120	6	2800 ohm 5 W		
LH 96/6*	240	6	6300 ohm 5 W		

*The resistor for this unit must be mounted externally due to length.

Dimensions (Approx.)

